

Disclaimer of Liability

This detail is meant to show the installation of the Tabs II Panel only. Always check first with the window manufacturer for their recommendation on how to flash & install their window.

FULL WIDTH WINDOW FLASHING BY WINDOW MFR/ SUPPLIER

SEALANT

SLOPE BRICK TO DRAIN 1/4" / 3"

BLOCKING LEVEL W/ TOP OF BRICK MINIMUM

SELF-ADHEREING FLEXIBLE FLASHING EXTEND OVER WINDOW FULL WIDTH

MASTIC

MORTAR / GROUT

1/2" THICK MASONRY VENEER

SILL

TABS II PANEL

BUILDING WRAP

SUBSTRATE

SUPPORT TAB

3/8"

RECESSED WINDOW SILL DETAIL

SCALE: FULL

LAST REVISION: 01-26-05

